

SINGLE COMPONENT CARC MIL-DTL-53039

PRE-FILLED TOUCH-UP BRUSH AND ROLLER

DIRECTIONS FOR USE:

1. Shake bottle vigorously for 30 seconds.
2. Remove cap from bottle, puncture seal, and attach either brush or roller head by pressing head firmly onto the neck of the bottle before screwing on.
3. Squeeze bottle until paint appears on brush or roller.
3. Apply liberal first coat by brushing or rolling vertically across area requiring touch-up.
4. Wait 3-5 minutes.
5. Apply second coat by first brushing or rolling vertically, then brushing or rolling horizontally to assure proper coverage.



NOTES:

- (1) Always wear protective clothing, eye protection, gloves and a respirator per your local requirements.
- (2) To extend shelf-life, puncture seal of 1-ounce bottle of nitrogen using yorker tip, place yorker tip onto nitrogen bottle and squeeze once into paint bottle. Reseal paint bottle with new cap supplied. Do not squeeze nitrogen bottle more than once as it will draw the nitrogen back out of bottle.
- (3) Between uses it may be necessary to replace foam roller or brush head. Use extra foam or brush head included with kit.

To use extra foam: While wearing gloves, remove center plastic piece on head. Slide current foam off and replace with new foam. Snap piece back in place on head, squeeze bottle until paint appears on roller, and begin rolling.



MILSPRAY

Military Technologies

845 Towbin Avenue . Lakewood, NJ 08701
Phone 732-886-2223 . Fax 732-886-2250
Email: customerservice@milspray.com
Website: www.milspray.com
Cage Code: 3NXX3